



Anti-slip Tape Installation Instructions

- Testing of adhesive before installation is suggested.
- Repair application area by filling any cracks or pits. Seal porous surfaces. DO NOT apply over grout lines.
- Surface temperature must be above 50°F and below 100°F
- Clean surface using industrial cleaner. Remove any oils, dirt and loose paint, area must be free of debris.
- Flush surface to remove any residue.
- Allow ample dry time, surface must be clean and dry.
- Cut to size. Rounding corners is suggested.
- Apply to clean, dry, flat surface by peeling off paper backing, keeping fingers off adhesive.
- Position and press in to place, pushing from the center out to the edges to remove any air bubbles. For enhanced bond use a rubber hand roller.
- Ready for immediate use.
- Surface can be cleaned using mild floor cleaner as directed.

*Use on new pressure treated lumber is not recommended. Lumber must be cured or dried for 6-12 months (based on environmental conditions) prior to anti-slip tape installation for proper adhesion.